
Checking Thermistor Resistance through the Case Connector



You'll need to pin out between Pin# 3 & 8 (See Below)

The Thermistor is located in the Governor pressure sensor, the image below gives the Torque setting for the screws that hold the harness in place.

